

CMSV

Live Camera & Location Management

Live video, GPS tracking, intercom and video management for a matched camera, firmware and network deployment.

View live camera video

Access live video from compatible connected cameras through the configured system.

Follow location information

Use GPS tracking where the selected camera and firmware provide compatible location data.

Communicate and manage video

Use intercom alongside video uploading and management in the selected deployment.



Interface preview; build and configuration may vary

Live video

Connected camera viewing

GPS tracking

Compatible location data

Intercom

Camera communication

PLAN YOUR PRODUCT CONFIGURATION

Talk to Peter Pen about your application, model and project.

Email Peter

Call +86 13798434740

SPIKECAM LIMITED

spikecam.com

Hong Kong: 10/F, Corporation Park, 11 On Lai Street, Sha Tin, New Territories, Hong Kong

Peter Pen

info@spikecam.com

Tel / WhatsApp: +86 13798434740

Technical specifications

Verified platform functions

Live video	Streaming from compatible connected cameras
Location	GPS tracking with supported camera location data
Communication	Intercom function
Video workflow	Video upload and management

Deployment requirements to confirm

Camera integration	Matching camera model, firmware and connectivity
Network service	Configured connection; bandwidth and data service to confirm
Host environment	Server/client OS, hardware sizing and hosting unconfirmed
Capacity & entitlement	Camera/user limits, storage and licensing unconfirmed

Configuration notes

Live functions require a compatible camera, firmware and configured network.

Confirm hosting, camera/user capacity, data service and licensing for the selected CMSV build.

The interface image is illustrative; displayed layouts do not establish licensed capacity.