

DEMS Server/Client

Central Evidence Management Software

Centralize files from docking-station clients and manage server-held evidence with user/group permissions and network playback.

Collect across docking clients


Bring data from supported docking-station client software into one server management workflow.

Control user and group access

Assign permissions to different users and groups.

Review video over the network

Access server-held video for playback over the configured LAN or WAN.



Interface preview; build and configuration may vary

Server / client

Evidence architecture

User / group

Permission management

LAN / WAN

Network video playback

PLAN YOUR PRODUCT CONFIGURATION

Talk to Peter Pen about your application, model and project.

[Email Peter](#)

[Call +86 13798434740](#)

SPIKECAM LIMITED

spikecam.com

Hong Kong: 10/F, Corporation Park, 11 On Lai Street, Sha Tin, New Territories, Hong Kong

Peter Pen

info@spikecam.com

[Tel / WhatsApp: +86 13798434740](#)

Technical specifications

Verified evidence workflow

Architecture	Central server with docking-station clients
Collection	Receive data from multiple supported docking clients
Evidence management	Manage collected data on the server
User management	Permissions for individual users
Group management	Permissions for user groups
Playback access	Online video playback through configured WAN / LAN access

Deployment requirements to confirm

Client integration	Matched dock client, camera firmware and server version
Server platform	Supported OS, database and hardware sizing unconfirmed
Storage & licensing	Capacity, retention, client/user limits and entitlement unconfirmed

Configuration notes

Confirm the docking client and server versions as one evidence deployment.

Confirm server OS, storage, network access and license scope before installation.

The interface shows sample records; pictured data and controls are illustrative.